



ATTENTION:

When installing glass insert

Glass insert (when installed correctly) will be held **tight** by vinyl retainer strips.

CAUTION!

If glass insert is **loose**—vinyl retainer strips are **NOT** installed correctly. Refer to the “Glass Insert Installation/Removal” section of your manual and re-install the retainer strips.

